



# HOW TO TRANSITION EPOXY TERRAZZO TO SIMIX HIGH SHINE CERAMIC COATING

## Tools & Supplies Needed

- Simix High Shine Ceramic Floor Coating
- Stripper
- Water
- Mop and bucket
- Tac strip mop
- Looped microfiber flat mop
- Fan
- Burnisher
- Auto scrubber
- 220 grit diamond pads
- 200 diamond discs
- 400 diamond discs
- 800 diamond discs
- 3000 diamond pads
- red pads

## PREP SURFACE

1. Strip and rinse floor with a 220 diamond pad to remove all residue.
2. Next, hit the floor with a 200 diamond disc. Do 6 to 8 passes both ways.
3. Pick up slurry and rinse floor with red pads.
4. After rinsing, reapply fresh water for next diamond disc.
5. Place the four 400 diamond discs on the pad at opposite corners. Do four passes both ways.
6. Pick up slurry and rinse.
7. Then, using the 800 discs, do four passes both ways.

8. Pick up slurry and rinse.
9. Clean and rinse floor two more times. Clean edges and corners.
10. Let dry.
11. Burnish with 3000 diamond pad, 2 to 3 passes both ways.
12. Clean floor of all burnishing dust using a tac strip dust mop or wet rinse.

### **COAT THE FLOORS**

1. Mix Simix High Shine Ceramic Coating at 4 parts water to 1 part coating.
2. Use looped microfiber flat mop to apply to floor.
3. Allow floor to dry between coats. Simix dries quickly.
4. Apply 4 coats.

### **ONE WEEK LATER**

1. Clean floor.
2. Burnish with 3000 diamond.
3. Apply 4 more coats.